

QUICK START USER GUIDE

The CMI165 is a hand-held instrument for high precision measurement of copper thickness. Automatic temperature correction provides accurate measurements at temperatures above and below room ambient.

OPERATION

STARTING UP THE CMI165

Place the gauge on a copper surface or press any button.

MEASURING WITH THE CMI165

Place the gauge on a copper surface and the measured thickness will be displayed. Press the Left button to return to the menu.

USING THE CMI165 CONTROLS

All paths, e.g. *Settings/Display/Backlight/Yes or No*, start from the Main menu.

| FEATURE | ACTION |
|--------------------------|---|
| Turn on the CMI165 | Press any button or place gauge on copper surface |
| Turn off the CMI 165 | Press and hold the Center button |
| Turn backlight on or off | Press and hold the Left button or <i>Settings/Display/Backlight/</i> |
| Select a menu item | Scroll to the item pressing the Up or Down buttons and press the Center or Right buttons to select it |

The information in this document is private and confidential and must not be copied.
Oxford Instruments America, Inc., A subsidiary of Oxford Instruments plc

| | |
|---------------------------------------|--|
| Go back to the previous menu | Press the Left button |
| Change Units | <i>Settings/Measure/Parameters/Units</i> |
| Change a memory location | Select <i>Memory/Location</i> Enter a number (1 to 99) pressing the Up/Down buttons to increment or decrement a digit and the Right/Left buttons to go to the next/previous digit. When at farthest right position press Right button to complete the entry. |
| Change Cu Type | <i>Settings/Measure/Parameters/Cu Type</i> Select Cu for electro deposited copper or ECu for electroless copper. |
| View Statistics | Select <i>Stats/View</i> Press the Up/Down buttons to scroll through the list. Press Left button to return to the menu |
| Clear Statistics | Select <i>Stats/Clear/Clear Stats</i> |
| Clear last reading from statistics | Press and hold the Down button after taking a measurement |
| Display last reading from statistics | Select Measure from the Main menu |
| Upload statistics or readings to a PC | Select <i>Stats/Export/Stats, Data, Histogram or All</i> ; or select <i>Stats/Upload Rdgs.</i> See installation CD |

The information in this document is private and confidential and must not be copied.
Oxford Instruments America, Inc., A subsidiary of Oxford Instruments plc

SPECIFICATIONS

MATERIALS

- CMI165 Gauge and patented integral probe with temperature compensation (US 7,148,712)
- OICM Certified ½ oz Standard

CALIBRATION

- Auto correct measurement of lines
- Factory Calibrated

MEMORY STRUCTURE

- Locations 01 to 99 available
- Current location shown in the upper left of display
- Stores readings and corresponding statistics, Copper (Cu) Type, Measure Lines, Conductivity Factor (CF) and Offset parameters.

Cu TYPE

- Electrodeposited: 10µin/0.25µm – 10mil/254µm
- Electroless: 10µin/0.25µm – 500µin/12.7µm

PROBE TIP

- Replaceable temperature compensating module

MEASURE LINES

- Auto correction for printed circuit board traces
- Width range: 8mil/204µm to 3000mil/76,200µm

CONDUCTIVITY FACTOR (CF)

- Used when readings differ from known value
- $CF = \text{Desired reading} / \text{Actual Reading}$
- Range is 0.5 to 4

OFFSET

- Subtracted from reading
- Range is 0.0 to Cu type max thickness. See Cu Type above

OPERATING MODES

| MODE | MENU SETTING | MEASUREMENT |
|------------|--------------|---|
| Auto | Auto | Last reading passed to statistics |
| Continuous | Cont | None taken |
| Manual | Manual | Last reading passed to statistics when center button is pressed |

LOW BATTERY

- Indicated when battery symbol is not shaded
- Replace batteries with two AA types

SAMPLE FOR MEASUREMENT

- Must be clean and free of surface defects

CONTACT OXFORD INSTRUMENTS

Support 847-439-4404 X304

e-mail support@msys.oxinst.com

Sales 847-439-4404 X322 800-678-1117

e-mail sales@msys.oxinst.com

Download Manual www.oicm.com

User Guide Part Number 51-98-3990-00006 Rev. C